

Annotation:

The present information bulletin contains modified data on operation of tractors BELARUS-92II completed with a distributor PII70 with one valve fixed in “Uplift” position.

Content of changes:

1 Unit “3. Controls and instruments”, subsection “3.13 Control of a distributor (remote hydraulic cylinders) and a pump of hydraulic system of rear lift linkage”, clause “3.13.2 Control of a distributor of hydraulic lift linkage” shall be amended and supplemented as follows:

-the information available: “Uplift” is a lower fixed position with automatic return. In “Uplift” position with the engine operating the lever returns into “Neutral” position as the pressure of automatic return is achieved (completion of cylinder stroke).

-shall be replaced with: “Uplift” is a lower fixed position with automatic return for a distributor P80-3/1-222. The levers return to “Neutral” position automatically with the pressure from 16,5 to 20 MPa. For distributors RS213Mita, PII70-1221 and PII70-890 the position is nonfixed. When released the levers return to “Neutral” position.

Against order the tractors may be equipped with a distributor PII70 with fixation of a valve, controlling right side outlet, in “Uplift” position without automatic return to “Neutral” position.

ATTENTION: WHEN OPERATING WITH THE USE OF THE MENTIONED VALVE IN THE POSITION “UPLIFT” DON'T FORGET TO SET THE VALVE CONTROL LEVER INTO “NEUTRAL” POSITION AFTER COMPLETION OF THE OPERATION IN ORDER TO PROTECT THE HYDRAULIC SYSTEM FROM OVERHEATING AND PREMATURE FAILURE OF THE PUMP AND OTHER UNITS OF THE HYDRAULIC SYSTEM!