



БЮЛЛЕТЕНЬ

BULLETIN

1523-0000010 РЭ

Руководство по эксплуатации

Operator's manual

Количество листов

4

Quantity of sheets

Лист

1

Sheet

ОСНОВАНИЕ: ПК 1500-308

GROUND: PK 1500-308

Бюллетень Bulletin 2-2011 БЭ	МОДЕЛЬ ТРАКТОРА TRACTOR MODELS	БЕЛАРУС-1523/1523В/1523.3/1523В.3
---	-----------------------------------	-----------------------------------

Аннотация:

В настоящем эксплуатационном бюллетене приведены измененные сведения по эксплуатации тракторов БЕЛАРУС-1523/1523В/1523.3/1523В.3 в комплектации с электрогидравлическим блоком РП70-1523.

Содержание изменений:


1. Раздел «Устройство и работа составных частей трактора» подраздел «Гидронавесная система».

Стр. 151 заменить:

Имеется:

Электрогидравлический блок (РП70 + ЕНРНС1-ОС)

Электрогидравлический блок (РП70 + ЕНРНС1-ОС) состоит из электрогидравлического регулятора производства фирмы «Argo-Hytos» (Чехия) в комплекте с распределительными секциями распределителя РП70 производства завода «Гидропривод» РБ.




1- Крышка РП70-20; 2 - Секции распределителя РП70-8-0-М; 3 - Регулятор ЕНРНС1-ОС

- должно быть:

Электрогидравлический блок РП70-1523.

Электрогидравлический блок РП70-1523 состоит из электрогидравлического регулятора производства «Argo-Hytos» (Чехия) в комплекте с распределительными секциями распределителя РП70 производства завода «Гидропривод» РБ. Золотник крайней правой секции имеет фиксацию в позиции «Подъем».

ВНИМАНИЕ: РЫЧАГ УПРАВЛЕНИЯ КРАЙНЕЙ ПРАВОЙ СЕКЦИЕЙ ПРИ УСТАНОВКЕ В ПОЗИЦИЮ «ПОДЪЕМ» ПОСЛЕ ВЫПОЛНЕНИЯ ОПЕРАЦИИ ДОЛЖЕН ПРИНУДИТЕЛЬНО ВОЗВРАЩАТЬСЯ В ПОЗИЦИЮ «НЕЙТРАЛЬ» ВРУЧНУЮ.



Электрогидравлический блок РП70-1523.

- 1 – Регулятор ЕНРНС1-ОС*
- 2 – Секция распределителя РП70-8-0-М*
- 3 – Секция распределителя РП70-8-1-М*
- 4 – Крышка РП70-20;*

Annotation:

In the present information bulletin the updated information on operating tractors BELARUS - 1523/1523B/1523.3/1523B.3 in a set with electrohydraulic module ПИ70-1523 is provided:

Content of changes:


1. Unit “Structure and function of the main tractor components”, subsection “Hydraulic lift linkage”.

The following changes shall be made at page 151:

The information available:

Electrohydraulic module (ПИ70 + EHPHC1-OC)

Electrohydraulic module (ПИ70 + EHPHC1-OC) consists of electrohydraulic governor, made by “Argo-Hytos” (Czech Republic) in a set with distribution panels of the control valve ПИ70, produced by the plant “Hydroprivod”, the Republic of Belarus.




1 – Cover ПИ70-20; 2 – Distribution panel ПИ70-8-0-M; 3 – Governor EHPHC1-OC

- shall be replaced with:

Electrohydraulic module ПИ70-1523.

Electrohydraulic module ПИ70-1523 consists of electrohydraulic governor, made by “Argo-Hytos” (Czech Republic) in a set with distribution panels of the control valve ПИ70, produced by the plant “Hydroprivod”, the Republic of Belarus. The valve spool of the rightmost panel is fixed in the position “Lift”.

ATTENTION: WHEN SET INTO POSITION “LIFT”, THE CONTROL LEVER OF THE RIGHTMOST PANEL SHALL BE MANUALLY RETURNED TO “NEUTRAL” POSITION AFTER THE OPERATION IS FINISHED.



Electrohydraulic module ПИ70-1523

- 1 – Governor EHPHC1-OC
- 2 – Distribution panel ПИ70-8-0-M
- 3 – Distribution panel ПИ70-8-1-M
- 4 – Cover ПИ70-20